


## Baterie Duracell JVC, BN-VF714U, 7,2V (7,4V) - 1540mAh

Kód (DR9657)



### Kompatibilita dle výrobního čísla:

#### Videokamery

JVC GR-DF420, GR-DF425, GR-DF430, GR-DF430US, GR-DF450, GR-DF450U, GR-DF450US, GR-DF470, GR-DF470US, GR-DF540, GR-DF550, GR-DF550U, GR-DF550US, GR-DF565, GR-DF570, GR-DF570US, GR-DF590, GR-D239, GR-D240, GR-D244US, GR-D246, GR-D247, GR-D250, GR-D250AC, GR-D250U, GR-D250US, GR-D270, GR-D270AC, GR-D270U, GR-D270US, GR-D271, GR-D271US, GR-D275, GR-D275U, GR-D275US, GR-D29, GR-D290, GR-D290AC, GR-D290AH, GR-D290US, GR-D295, GR-D295US, GR-D320, GR-D320EX, GR-D328EF, GR-D329AH, GR-D338AH, GR-D340, GR-D340EX, GR-D350, GR-D350AC, GR-D350AH, GR-D350U, GR-D350US, GR-D360, GR-D360EX, GR-D370, GR-D370AC, GR-D370AH, GR-D370EX, GR-D370U, GR-D370US, GR-D371US, GR-D375U, GR-D375US, GR-D390U, GR-D390US, GR-D395US, GR-D396US, GR-D640, GR-D640EX, GR-D650, GR-D650AC, GR-D650AH, GR-D650E, GR-D650EX, GR-X5, GR-X5AC, GR-X5E, GR-X5US, GZ-DF420, GZ-DF470, GZ-D240, GZ-D270, GZ-MG20, GZ-MG20U, GZ-MG20US, GZ-MG21, GZ-MG21AC, GZ-MG21EX, GZ-MG21US, GZ-MG26, GZ-MG27, GZ-MG27AH-U, GZ-MG27EX, GZ-MG27US, GZ-MG30, GZ-MG30U, GZ-MG30US, GZ-MG31, GZ-MG31AC, GZ-MG35US, GZ-MG36EK, GZ-MG37, GZ-MG37AH-U, GZ-MG37EX, GZ-MG37US, GZ-MG40, GZ-MG40US, GZ-MG47, GZ-MG47EX, GZ-MG50, GZ-MG50US, GZ-MG505, GZ-MG505AC, GZ-MG505B, GZ-MG505EK, GZ-MG505S, GZ-MG505US, GZ-MG57, GZ-MG57AC, GZ-MG57AH-U, GZ-

MG57EK, GZ-MG60, GZ-MG67, GZ-MG67AC, GZ-MG67AH-U, GZ-MG67EX, GZ-MG67US, GZ-MG70, GZ-MG70US, GZ-MG77, GZ-MG77AC, GZ-MG77AH-U, GZ-MG77EX, GZ-MG77US

**Kompatibilita dle výrobního čísla:**

BN-VF707, BN-VF707U, BN-VF707UE, BN-VF707US, BN-VF714, BN-VF714U, BN-VF714UE, BN-VF714US, LY34647-002B, VIJV-714-174