


## Baterie Duracell Panasonic CGA-S006, 7,2V (7,4V) - 700mAh

Kód (DR9668)



### Kompatibilita dle výrobního čísla:

BP-DC5-E, BP-DC5 J, BP-DC5 U, CGA-S006, CGA-S006E, CGA-S006E/1B, CGR-S006, CGR-S006A/1B, CGR-S006E, CGR-S006E/1B, DMW-BMA7

### Kompatibilita dle modelu:

Fotoaparáty

LEICA  
V-LUX1

### PANASONIC

Lumix DMC-FZ18, Lumix DMC-FZ18EB-K, Lumix DMC-FZ18EG, Lumix DMC-FZ18EG-K, Lumix DMC-FZ18EG-S, Lumix DMC-FZ18GK, Lumix DMC-FZ18K, Lumix DMC-FZ18S, Lumix DMC-FZ28, Lumix DMC-FZ28EF-K, Lumix DMC-FZ28EF-S, Lumix DMC-FZ28GK, Lumix DMC-FZ28K, Lumix DMC-FZ28S, Lumix DMC-FZ30, Lumix DMC-FZ30BB, Lumix DMC-FZ30EE-K, Lumix DMC-FZ30EE-S, Lumix DMC-FZ30EG, Lumix DMC-FZ30EG-K, Lumix DMC-FZ30EG-S, Lumix DMC-FZ30GK, Lumix DMC-FZ30-K, Lumix DMC-FZ30PP, Lumix DMC-FZ30-S, Lumix DMC-FZ35, Lumix DMC-FZ35K, Lumix DMC-FZ38, Lumix DMC-FZ38K, Lumix DMC-FZ50, Lumix DMC-FZ50EB-K, Lumix DMC-FZ50EB-S, Lumix DMC-FZ50EE-K, Lumix

DMC-FZ50EE-S, Lumix DMC-FZ50EF, Lumix DMC-FZ50EGM, Lumix DMC-FZ50K, Lumix DMC-FZ50S, Lumix DMC-FZ7, Lumix DMC-FZ7BB, Lumix DMC-FZ7BS, Lumix DMC-FZ7EB-K, Lumix DMC-FZ7EB-S, Lumix DMC-FZ7EE-K, Lumix DMC-FZ7EE-S, Lumix DMC-FZ7EF-K, Lumix DMC-FZ7EF-S, Lumix DMC-FZ7EG-K, Lumix DMC-FZ7EG-S, Lumix DMC-FZ7GK, Lumix DMC-FZ7-K, Lumix DMC-FZ7-S, Lumix DMC-FZ8, Lumix DMC-FZ8EB-K, Lumix DMC-FZ8EB-S, Lumix DMC-FZ8EF-S, Lumix DMC-FZ8EG, Lumix DMC-FZ8GK, Lumix DMC-FZ8K, Lumix DMC-FZ8S