


# Baterie Duracell Canon NB-2L, 7,2V (7,4V) - 650mAh

**Kód (DRC2L)**



## **Kompatibilita dle výrobního čísla**

CANON  
BP-2LH, BP-2L5, E160814, NB-2L, NB-2LH, 9612A001AB

## **Kompatibilita dle modelu Fotoaparáty**

CANON  
EOS Kiss Digital N, EOS Kiss Digital X, EOS 350D, EOS 400D, PC1018, PowerShot G7, PowerShot G9, PowerShot S30, PowerShot S40, PowerShot S45, PowerShot S50, PowerShot S60, PowerShot S70, PowerShot S80

## **Kompatibilita dle modelu Videokamery**

CANON  
DC301-420 DC301, DC310, DC320, DC330, DC410, DC420 TOP BATTERY, s.r.o., Pražská 68/12, 102 00 Praha 10

## **ELURA**

40-90 Elura 40MC, Elura 50, Elura 60, Elura 65, Elura 70, Elura 80, Elura 85, Elura 90

## **ES300V-8200V**

ES-300V, ES-4000, ES410V 8mm, ES-50, ES-5000, ES-520A, ES-55, ES-6000, ES-6500V, ES-7000es, ES-7000V, ES-8000V, ES-8100H18, ES-8100V, ES-8200V

FVM100-500

FVM100, FVM20, FVM200, FVM30, FV500

GL,HV,iVIS,IXY,LEGRIA,MD

GL-1, GL2, HG10, HV20, HV30, iVIS DC300, iVIS HG10, iVIS HV30, IXY DVM3, IXY DV3, IXY DV5, LEGRIA HF R106, LEGRIA HF R16, LEGRIA HF R17, LEGRIA HF R18, MD100, MD101, MD110, MD111, MD120, MD130, MD140, MD150, MD160, MD215, MD225, MD235, MD245, MD255, MD265

MVX,MV

MVX20i, MVX200, MVX200i, MVX25i, MVX250i, MVX30i, MVX300, MVX330i, MVX35i, MVX350i, MVX40, MVX40i, MVX45i, MV5, MV5i, MV5iMC, MV6iMC, MV790, MV800, MV800i, MV830, MV830i, MV850i, MV880X, MV880Xi, MV890, MV900, MV901, MV920, MV930, MV940, MV950, MV960

OPTURA,UC,VIXIA,ZR

Optura 30, Optura 40, Optura 400, Optura 50, Optura 500, Optura 60, UC-V100, UC-V20Hi, UC-V200, UC-V30Hi, VIXIA HF R10, VIXIA HF R100, VIXIA HF R11, VIXIA HG10, VIXIA HV20, VIXIA HV30, VIXIA HV40, ZR100, ZR200, ZR300, ZR400, ZR500, ZR600, ZR700, ZR800, ZR830, ZR850, ZR900, ZR930, ZR950, ZR960 UC-V10Hi