


Duracell Panasonic VW-VBD140, 7,2V (7,4V) - 1440mAh

Kód (DR9608)



Kompatibilita dle výrobního čísla:

CGA-DU06, CGA-DU06A/1B, CGA-DU07, CGA-DU07A/1B, CGA-DU07E/1B, CGA-DU12, CGA-DU12A/1B, CGA-DU14, CGA-DU14A, CGA-DU14A/1B, CGA-DU14E/1B, CGR-DU06, CGR-DU07, CGR-DV06, DZ-BP07S, DZ-BP14S, DZ-BP14SJ, DZ-BP14SW, DZ-BP7S, DZ-BP7SJ, DZ-BP7SW, VIPA-DU14-532, VW-VBD070, VW-VBD120-H, VW-VBD140

Kompatibilita dle modelu – videokamery:

HITACHI

DZ-BX35A, DZ-BX37E, DZ-GX20, DZ-GX20A, DZ-GX20E, DZ-GX25M, DZ-GX3100, DZ-GX3100A, DZ-GX3100E, DZ-GX3200, DZ-GX3200A, DZ-GX3200E, DZ-GX3300A, DZ-GX3300(B), DZ-GX3300E, DZ-GX3300(S), DZ-GX5000A, DZ-GX5020A, DZ-GX5060SW, DZ-GX5080A, DZ-GX5100SW, DZ-GX5300, DZ-HS300, DZ-HS300A, DZ-HS300E, DZ-HS301E, DZ-HS301SW, DZ-HS303, DZ-HS303A, DZ-HS303E, DZ-HS303SW, DZ-HS401, DZ-HS403, DZ-HS500A, DZ-HS500SW, DZ-HS503, DZ-MV350, DZ-MV350A, DZ-MV350E, DZ-MV380, DZ-MV380A, DZ-MV380E, DZ-MV550, DZ-MV550A, DZ-MV550E, DZ-MV580, DZ-

MV580A, DZ-MV580E, DZ-MV730, DZ-MV730A, DZ-MV730E, DZ-MV750, DZ-MV750E, DZ-MV750MA, DZ-MV780, DZ-MV780A, DZ-MV780E, DZ-MV780R, DZ-MV780S, DZ-M5000V5, DZ-M7000V5, DZ-M8000V6

PANASONIC

NV-GS10, NV-GS10B, NV-GS10EG, NV-GS10EG-A, NV-GS10EG-R, NV-GS10EG-S, NV-GS100K, NV-GS120, NV-GS120B, NV-GS120EG-S, NV-GS120GN, NV-GS120GN-S, NV-GS120K, NV-GS140, NV-GS140EG-S, NV-GS150, NV-GS150B, NV-GS150EG-S, NV-GS158GK, NV-GS17, NV-GS17EF-S, NV-GS180, NV-GS180EB-S, NV-GS180EG-S, NV-GS200, NV-GS200B, NV-GS200EG-S, NV-GS200GN, NV-GS200K, NV-GS21, NV-GS22, NV-GS22EG-A, NV-GS22EG-S, NV-GS230, NV-GS230EB-S, NV-GS230EG-S, NV-GS250, NV-GS250B, NV-GS250EG-S, NV-GS258GK, NV-GS27, NV-GS27EB-S, NV-GS27EF-S, NV-GS27EG-S, NV-GS28GK, NV-GS280, NV-GS280EB-S, NV-GS280EG-S, NV-GS30, NV-GS30B, NV-GS300, NV-GS300EB-S, NV-GS300EG-S, NV-GS320, NV-GS320EB-S, NV-GS320EG-S, NV-GS33, NV-GS33EG-S, NV-GS330EP-S, NV-GS35, NV-GS37, NV-GS37EB-S, NV-GS37EG-S, NV-GS38GK, NV-GS40, NV-GS40B, NV-GS400, NV-GS400B, NV-GS400EG-S, NV-GS400GN, NV-GS400K, NV-GS408GK, NV-GS44, NV-GS50, NV-GS50A, NV-GS50A-S, NV-GS50AW, NV-GS50B, NV-GS50K, NV-GS50V, NV-GS500, NV-GS500EB-S, NV-GS500EG-S, NV-GS55, NV-GS55B, MNV-GS55EG-S, NV-GS55GN-S, NV-GS55K, NV-GS60, NV-GS60EB-S, NV-GS60EG-S, NV-GS65, NV-GS70, NV-GS70A, NV-GS70A-S, NV-GS70B, NV-GS70K, NV-GS75, NV-GS75B, NV-GS75EG-S, NV-GS78GK, NV-GS80, NV-GS80EG-S, NV-GS85, NV-MX500A, PV-GS120, PV-GS150, PV-GS180, PV-GS19, PV-GS200, PV-GS250, PV-GS29, PV-GS300, PV-GS31, PV-GS320, PV-GS33, PV-GS34, PV-GS35, PV-GS36, PV-GS39, PV-GS400, PV-GS50, PV-GS50K, PV-GS50S, PV-GS500, PV-GS55, PV-GS59, PV-GS65, PV-GS70, PV-GS75, PV-GS80, PV-GS85, SDR-H18, SDR-H20, SDR-H20EB-S, SDR-H200, SDR-H250, SDR-H250EG-S, SDR-H280, VDR-D100, VDR-D100EB-S, VDR-D150, VDR-D150EB-S, VDR-D150EF-S, VDR-D150EG-S, VDR-D158GK, VDR-D160, VDR-D160EB-S, VDR-D160EG-S, VDR-D200, VDR-D210, VDR-D220, VDR-D220EB-S, VDR-D220EG-S, VDR-D220EP, VDR-D230, VDR-D250, VDR-D250EB-S, VDR-D250EG-S, VDR-D258GK, VDR-D300, VDR-D300EB-S, VDR-D300EG-S, VDR-D308GK, VDR-D310, VDR-D310EB-S, VDR-D310EG-S, VDR-D310EP, VDR-D400, VDR-M30, VDR-M30K, VDR-M50, VDR-M50B, VDR-M50EG-S, VDR-M50PP, VDR-M53, VDR-M55, VDR-M70, VDR-M70B, VDR-M70EG-S, VDR-M70K, VDR-M70PP, VDR-M75, VDR-M95